Hydro Step
SPC Vinyl Click Flooring



Hydrostep Wood Plank & Stone Tile Effect Flooring

Floor Care Instructions

Usage Areas:

Domestic/residential homes & light to moderate commercial usage
(small/medium size store & office areas).

Not guaranteed for conservatory/sun room use. Blinds/window coverings must be used to protect from direct sunlight where bi-fold doors and/or Velux windows are present.

*Compatible Underfloor Heating Systems:

- Concrete encased water piped underfloor heating systems - Max 27 ºc at floor level
- Electrical looselay & mat underfloor heating systems - Max 27 ºc at floor level

Post Installation

Hydro Step vinyl click flooring will retain its beauty and function for many years to come, but it does require simple care. Post Installation preparation is easy but crucial for the performance of your floor.

- Remove all loose debris from the floor by using a soft sweeping brush or dust mop.
- Use a damp mop with a non-abrasive, floor specific cleaning solution.

Routine Care

Ensure your floor lasts a lifetime by following the simple guidelines below.

- Sweep and dust mop regularly. If vacuuming, use vacuum head with a brush or felt, not a head equipped with a beater.
- Use a slightly damp mop with a reliable floor routine cleaner. **DO NOT** use bleach based products or washing up liquid.
- If using a steam mop, use only on a low setting.
- Attend to spillages immediately.
- Liberally apply the cleaning solution over a manageable area using a clean mop, then rinse off the cleaning solution and leave to dry.
- Do not use steel wool or scouring powder that will scratch the floor.
- Minimize abrasive and dirt by placing mats on both sides of exterior doors. Area rugs in high-traffic areas are also a good idea.
- Place protective pads beneath furniture legs and other heavy objects. Keep furniture casters clean. Keep pets' nails trimmed.
- Remove shoes with cleats, spikes or exceptionally pointy heels before walking on the floor.
- Take great care when moving furniture and large objects. Lay down a protective sheet or plywood.